



3M™ Speedglas™ 9100 Welding Helmet Care and Maintenance



To optimise the effective lifetime of your welding equipment and avoid the additional cost of replacement, regular maintenance is important.

Before Use

- Inspect inner and outer protection plates and filter glass. Replace if cracked, pitted or scratched
- Ensure low battery indicator is not flashing
- Inspect headband. Replace if damaged
- Inspect helmet for cracks. Replace if necessary
- Verify the sweatband is in place. Replace if necessary
- Replace any accessories used as necessary
- Check that the sensors on the welding filter are clean and uncovered

After Use

- Clean with cloth dampened with a mild solution of detergent and luke warm water
- Store in a dry, clean area / locker away from direct sunlight, high temperatures and solvents

Ordering Consumables, Repair Parts and Accessories


To request a quote or place an order for these items, please contact your 3M Approved Distributor.

Further Information and Advice

If you require additional guidance on the Care and Maintenance of your 3M Welding Equipment, please contact the Helpline or your local 3M representative.

3M Health & Safety Helpline
Monday - Friday 9 to 5
0870 60 800 60 UK
1 800 320 500 IRELAND

EAR
PELTOR



3M™ Speedglas™ 9100 Welding Helmet

	3M Part No
Welding helmet without SideWindows, with Speedglas 9100V filter, variable shade 5, 8, 9-13	50 11 05
Welding helmet without SideWindows with Speedglas 9100X filter, variable shade 5, 8, 9-13	50 11 15
Welding helmet without SideWindows, with Speedglas 9100XX filter, variable shade 5, 8, 9-13	50 11 25
Welding helmet with SideWindows, with Speedglas 9100V filter, variable shade 5, 8, 9-13	50 18 05
Welding helmet with SideWindows, with Speedglas 9100X filter, variable shade 5, 8, 9-13	50 18 15
Welding helmet with SideWindows, with Speedglas 9100XX filter, variable shade 5, 8, 9-13	50 18 25

3M™ Speedglas™ 9100 Welding Helmet accessories and spare parts

	3M Part No
Comfort sweatband, pkg of 3	16 80 15
Head protection, black	16 90 05
Neck protection, black	16 90 10
Hood, black/grey	16 91 00
Magnifying lens 1.0	17 10 20
Magnifying lens 1.5	17 10 21
Magnifying lens 2.0	17 10 22
Magnifying lens 2.5	17 10 23
Battery, pkg of 2	42 20 00
Speedglas 9100V welding filter, variable shade 5, 8, 9-13	50 00 05
Speedglas 9100X welding filter, variable shade 5, 8, 9-13	50 00 15
Speedglas 9100XX welding filter, variable shade 5, 8, 9-13	50 00 25
Speedglas 9100 helmet without SideWindows with headband	50 11 00
Speedglas 9100 helmet without SideWindows without headband	50 11 90
Speedglas 9100 helmet, with SideWindows with headband	50 18 00
Speedglas 9100 helmet, with SideWindows without headband	50 18 90
Outer protection plate standard, pkg of 10	52 60 00
Outer protection plate extra scratch resistant, pkg of 10	52 70 00
Outer protection plate heat resistant pkg of 10	52 70 70
Inner protection plate for Speedglas 9100V filter, pkg of 5 Plate marking 117x50	52 80 05
Inner protection plate for Speedglas 9100X, pkg of 5. Plate marking 117x61	52 80 15
Inner protection plate for Speedglas 9100XX, pkg of 5. Plate marking 117x77	52 80 25
Battery holder, pkg of 2	53 10 00
Heat reflecting silver front	53 20 00
SideWindows cover plate, 2 pairs	53 20 15
Speedglas 9100 headband including assembly parts	53 30 00
Pivot mechanism, left and right	53 60 00
Headband front part	53 61 00
Headband back part	53 62 00

@3M_UK_Safety

3M Personal Safety Division
3M United Kingdom plc
3M Centre
Cain Road, Bracknell
Berkshire RG12 8HT
Tel: 0870 60 800 60
www.3M.co.uk/Safety

3M Ireland Limited
The Iveagh Building
The Park
Carrickmines
Dublin 18
Tel: 1 800 320 500

17808
3M and Speedglas are trademarks of 3M Company
Please recycle. Printed in UK.
© 3M 2014. All rights reserved.

**REPLACE ALL DAMAGED PARTS IMMEDIATELY TO ENSURE
CORRECT LEVELS OF PROTECTION**



CH9100WCMP

To download this poster please visit:
www.3M.co.uk/maintenancepack or scan the QR code

